

NUT DRIVER OR SOCKET SET (FOR RACK ASSEMBLY TAPE MEASURE SCREW DRIVER DRILL AND 1/8" BIT

## **RACK ASSEMBLY:**

- 1. LAY ALL OF THE PIECES ON A FLAT WORK SURFACE, AS SHOWN, SO THAT THE HOOKS ARE ON THE INSIDE OF THE RACK.
- 2. POSITION THE TOP AND BOTTOM SPACERS BY SLIDING THE HOLES AT THE ENDS OVER THE SCREWS ALREADY INSTALLED IN THE UPRIGHTS.
- 3. SECURE THE SPACERS USING THE NYLOCK NUTS INCLUDED WITH THE RACK. (SEE DETAIL A)
- 4. TIGHTEN ALL HARDWARE.

## **INSTALLATION OF IN-COUNTER RACK:**

- 1. PLACE THE IN-COUNTER RACK INTO THE CABINET WITH THE HOOKS FACING THE FRONT AND SLIDE IT BACK UNTIL THE FRONT OF THE FRAME IS 9" FROM THE CABINET OPENING.
- 2. MARK THE LOCATION OF THE MOUNTING HOLES IN THE TOP AND BOTTOM SPACERS AND REMOVE THE UNIT FROM THE CABINET.
- 3. DRILL 1/8" STARTER HOLES IN THE LOCATIONS MARKED IN THE PREVIOUS STEP. BE CAREFUL NOT TO DRILL THROUGH THE TOP SURFACE OF THE CABINET.
- 4. POSITION THE IN-COUNTER RACK IN THE CABINET AND ALIGN THE HOLES IN THE TOP AND BOTTOM SPACERS WITH THE DRILLED HOLES IN THE CABINET.
- 5. SECURE USING THE APPROPRIATE FASTENERS.

## **SUGGESTIONS FOR INSTALLATION:**

- 1. I.R.S.G. CUSTOM SERIES IN-COUNTER RACKS CAN BE ORDERED IN CUSTOM SIZES TO FIT ANY HEIGHT OF CABINET.
- 2. THE CUSTOM SERIES RACK CAN BE MODIFIED BY THE USER BY CUTTING ONE END OF EACH UPRIGHT TO THE DESIRED LENGTH, TRIMMING THE HOOKS, AND RE-DRILLING THE BOLT HOLES IN THE UPRIGHTS.
- 3. IN-COUNTER RACKS MUST BE PROPERLY INSTALLED. FOR THE BEST RESULTS, INSTALL THE RACK IN THE CABINET WITH NO MORE THAN 1/4" CLEARANCE ABOVE THE TOP OF THE IN-COUNTER RACK.
- 4. IN-COUNTER RACKS ARE INTENDED TO HOLD I.R.S.G HANGERBARS. DO NOT USE THEM FOR ANY OTHER PURPOSE.

IN-COUNTER RACK DIMENSIONS			
	Α	В	
HANGERBAR	OVERALL	24" RACK	30" RACK
MODEL	WIDTH	HEIGHT	HEIGHT
21	20-15/16"	23-3/4"	29-7/8"
24	24-1/2"	23-3/4"	29-7/8"
30	29-15/16"	23-3/4"	29-7/8"

## International Retail Services Group

Customer Service: (888) 598-2001 · Web Site: www.irsg.com